

**Mitsubishi**

**ASX**

**N-ASX-SMART-P-22-1**

**2022**

**2.0L, 4-Cylinders**

**Smart Guide**

**SUV**

#### Dimensions

Exterior Dimensions L x W x H (mm)	4375 x 1770 x 1615
Wheelbase (mm)	2670
Ground Clearance (mm)	205
Weight (Kg)	1310

#### Engine & Drive Train

Displacement Cc	2000 Cc
HP	167 Hp
Torque	197 Nm
Type	MIVEC
Fuel System - Euro	Euro-4
Fuel Type	Petrol
Fuel Tank Capacity	63 L
Transmission	Automatic (CVT)
Drive Type	Two Wheel Drive
Differential Lock	X



### Exterior & Controls

Color	White
Wheel Size	18"-inch Alloy wheels (2ton)
Package	X
Doors	5-Doors
Sidestep	X
Keyless Entry	✓
Lights & Fog Lights	Halogen Light with Front & Rear Fog Lights
Spoiler	X
Camera	✓
Roof Rail	✓
Parking Sensor	X

### Interior

Color	Black
Seats	5-Leather Seats with White Diamond Stitches (Manual Seats)
Dashboard	Analog with Information Display
Steering	3-Spoke Leather-Wrapped Steering Wheel with Hands-Free & Audio Control
Parking Brake	Handbrake Lever
AC	Manual A/C
Sunroof	✓
Speakers	4-Speakers
Push Start	✓
Display Screen	✓

### Safety Features

Brake System	Electronic brakeforce distribution (EBD), Anti-lock braking system (ABS), Break Assist System (BAS)
Traction Control	X
Air Bags	Driver & Passenger Airbag, Front Side Seats Curtain Airbag, Driver Knee Airbag



Extra	
Display Audio with Navigation System	✓
Bluetooth	✓
Tire Pressure Monitoring System	✓
Front Door Locking & Unlocking Button	✓



ش م ح



NEW AUTO



NEW AUTO 1 FZ 0

نيو او تو

3 شرح









NEW AUTO

















### ① 注意事项

为保护您的行驶安全和隐私保护，在使用广汽三菱新，请务必仔细阅读，充分理解广汽三菱车载娱乐手册) 以及《广汽三菱车联网服务协议》，并在行驶过程中，请不要进行操作，请务必参考实际的况。如有任何疑问，请联系客服电话400-977-3099，service.gm3c@gm3c.com.cn.

同意

HOME BACK









**i 注意事项**

为了保护您的行驶安全和隐私保护，在使用广汽三菱车载娱乐系统前，请务必仔细阅读、充分理解广汽三菱车载娱乐系统《用户手册》以及《广汽三菱车联网隐私协议》，再点击同意。车辆行驶过程中，请不要进行操作，请务必参考实际的交通规则驾驶。如有任何疑问，请联系客服电话400-977-3030或发送邮件至 [service\\_gmmc@gmmc.com.cn](mailto:service_gmmc@gmmc.com.cn)。

**同意**

POWER HOME BACK MUTE



service\_gmmc@gmmc.com.cn

同意



HOME

BACK

MUTE







### ① 注意事项

本车搭载了三菱汽车自主研发的S-AWC系统，该系统可根据路况、车速、转向角度等信息，实时调整四驱系统的工作模式，以实现最佳的行驶稳定性和操控性。在使用过程中，请务必注意以下几点：

1. 请仔细阅读用户手册，了解S-AWC系统的操作方法和注意事项。

HOME BACK MUTE < >







