

Mitsubishi

Attrage

E16-1.2-P-23-02

2023

1.2L, 4-Cylinder

Medium-Line

Sedan

Dimensions	
Exterior Dimensions L x W x H (mm)	4305 x 1670x 1515
Wheelbase (mm)	2550
Ground Clearance (mm)	170
Weight (Kg)	1365Kg

Engine & Drive Train	
Displacement Cc	1198
HP	76 Hp
Torque	100Nm
Type	DOHC 12-Valve MIVEC Engine
Fuel System - Euro	Euro 2
Fuel Type	Petrol
Fuel Tank Capacity	42 L
Transmission	Automatic (INVECS-III, Continuously Variable Transmission)
Drive Type	2WD
Differential Lock	X

Contact: +971 56 998 6452
+971 50 849 4289



Exterior & Controls

Color	Grey
Wheel Size	15" Alloy Wheels
Package	X
Doors	5 Doors
Sidestep	X
Keyless Entry	X
Lights & Fog Lights	Halogen Headlamp & Front Fog Lamp
Spoiler	✓
Camera	X
Roof Rail	X
Parking Sensor	X

Interior

Color	Grey
Seats	5-Seaters (Fabric Seats)
Dashboard	Analog Speedometer with Information Dashboard
Steering	Leather Wrapped Steering Wheel with Audio Control, Hands-Free Telephone System & Cruise Control
Parking Brake	Parking Brake Lever
AC	Manual A/C
Sunroof	X
Speakers	4 Speakers
Push Start	X
Display Screen	Touch Multi-Media Display

Safety Features

Brake System	Electronic Brake force distribution with Brake Assist System (Hydraulic)
Traction control	Traction Control System
Air Bags	Driver & Passenger Airbags



	Extra	
Cruise Control		✓





NEW AUTO

NEW AUTO

NEW AUTO 1 FZ O



شرح

نيو اوتو





NEW AUTO 3 FZCO



3 ش م ح

نيواوتو



NEW AUTO 1

NEW AUTO





Attrage



NEW LIST



د.ع.م. ٢٠١٤
DANGER - خطر
!
لا تقرب من حواف الطرق
من دون حذر
Main Workup (Highground Transmission Line)
(Warning to Motorist)

Attrage



EV AUTO







NEWSPOTO





مناصات ويند المر

MODE

CANCEL SET

Source
FM 87.5 MHz
Presets
1 87.5 MHz 2 87.5 MHz 3 87.5 MHz
4 87.5 MHz 5 87.5 MHz 6 87.5 MHz
Manual AF



SRS AIRBAG





CANCEL

SET —



FM 20:14:25

Source

FM 12 87.5 MHz

Preset

7	87.5 MHz	8	87.5 MHz	9	87.5 MHz
10	87.5 MHz	11	87.5 MHz	12	87.5 MHz

Manual AF TP

8740A139

Temperature and fan controls

Left knob: Temperature (blue/red scale)

Middle knob: Fan speed (OFF, 1, 2, 3, 4)

Right knob: Air distribution (defrost, floor, dash)

Lock/unlock buttons

Left: Lock (car icon)

Right: Unlock (car icon)



P

R

N

D

B







 NEW AUTO



NEW AUTO